

QUICK INSTALL GUIDE

IMPORTANT TIPS

- Mount device inside dash at highest position with sticker (bar codes) facing down. Note: **DO NOT PLACE DEVICE UNDER ANY METAL.**

BEFORE CONNECTING TO CONSTANT POWER-ALL WIRES MUST BE CONNECTED (OR INSULATED) TO AVOID ELECTRICAL DAMAGE

- Locate and connect power wires from OBDII or Standard Harnesses.
- Connect relay and relay socket for starter disable, if applicable.
- Plug P1 connector to device which supplies power, chassis ground, ignition input, and starter disable output.
- Verify LED Status:
 - Orange:** GSM/GPRS= **Blinking**-searching for cellular signal. **Solid**-signal lock.
 - Green:** GPS= **Blinking**-searching for GPS signal. **Solid**-GPS lock.
- Log on to system to verify communication, and to confirm proper starter disable functionality, if applicable.

INSTALLATION COMPLETE

